

Section 6 Ice Harbor Dam

1. Fish Passage Information.....	IHR- 1
1.1. Juvenile Fish Passage.....	IHR- 1
1.2. Adult Fish Passage.....	IHR- 1
2. Project Operation	IHR- 4
2.1. Spill Management	IHR- 4
2.2. Dissolved Gas Management and Control	IHR- 4
2.3. Operating Criteria	IHR- 4
3. Project Maintenance	IHR-13
3.1. Juvenile Fish Passage Facilities.....	IHR-14
3.2. Adult Fish Passage Facilities	IHR-15
4. Turbine Unit Operation and Maintenance	IHR-17
4.1. Turbine Unit Operation.....	IHR-17
4.2. Turbine Unit Outages During High River Flow Periods	IHR-19
4.3. Turbine Unit Maintenance	IHR-20
5. Forebay Debris Removal	IHR-24

Ice Harbor Dam

1. Fish Passage Information. The locations of fish passage facilities at Ice Harbor Lock and Dam are shown in **Figure IHR-1**. Dates of project operations for fish purposes and special operations are listed in **Table IHR-1**.

1.1. Juvenile Fish Passage.

1.1.1. Facilities Description. The juvenile fish passage facilities at Ice Harbor consist of standard length submersible traveling screens, vertical barrier screens, 12" orifices, collection channel and dewatering structure, sampling facilities, transportation flume/pipe to the tailrace below the project, and a full-flow PIT tag detection system.

1.1.2. Juvenile Migration Timing. Juvenile passage timing at Ice Harbor Dam corresponds closely with juvenile passage at Lower Monumental Dam (**Table LMN-1**). Salmon, steelhead, bull trout, lamprey, and other species are routinely counted when sampling occurs at Ice Harbor. Maintenance of juvenile fish passage facilities that may impact juvenile fish passage or facility operations should be conducted during the winter maintenance season.

1.2. Adult Fish Passage.

1.2.1. Facilities Description. The adult fish passage facilities at Ice Harbor are made up of separate north and south shore facilities. The north shore facilities include a fish ladder with counting station, a small collection system, and a pumped auxiliary water supply system. The collection system includes two downstream entrances and one side entrance into the spillway basin. In normal operation one downstream entrance is used and the other two entrances are closed. The auxiliary water is supplied by two electric pumps with a third pump as a backup. The south shore facilities are comprised of a fish ladder with counting station, two south shore entrances, a powerhouse collection system, and a pumped auxiliary water supply system. The powerhouse collection system includes two downstream entrances and one side entrance into the spillway basin at the north end of the powerhouse, four operating floating orifices, and a common transportation channel. One of the downstream north powerhouse entrances and four of the floating orifices are used during normal operation. At the south shore entrances, one entrance is normally used. The auxiliary water is supplied by eight electric pumps of which from six to eight are normally used to provide the required flows. The excess water from the juvenile fish passage facilities is routed into the fish pump discharge chamber to provide additional attraction flow. The upper ends of both ladders have PIT tag detectors.




Figure IHR-1 Ice Harbor Lock and Dam General Site Plan

Table IHR-1. Dates of Project Operations for Fish Purposes at Ice Harbor Dam, 2010-11

Task Name	Start	Finish	FPP Reference	Qtr 2, 2010			Qtr 3, 2010			Qtr 4, 2010			Qtr 1, 2011		
				Mar	Apr	May	Jun	Jul	Aug	Sep	Oct	Nov	Dec	Jan	Feb
Maintenance of Adult Facilities	1/1/10	2/28/10	Ihr 1.2.2												
Adult Fish Passage Period	3/1/10	12/31/10	Ihr 2.3.2.2												
Weekly Reports	3/1/10	12/31/10	Ihr 2.3.3.1												
Operate Turbines for Fish Passage	3/1/10	11/30/10	Ihr 4.1												
1% limitations	3/1/10	2/28/11	Ihr 4.1.2												
1% Soft	3/1/10	3/31/10	Ihr 4.1.2												
1% Hard	4/1/10	10/31/10	Ihr 4.1.2												
1% Soft	11/1/10	2/28/11	Ihr 4.1.2												
TDG Monitoring	3/1/10	2/28/11	App D Table 4 Ihr												
Winter Maintenance Period Juvenile	3/1/10	3/31/10	Ihr 2.3.1.1.												
Back flush orifices once per shift	4/1/10	7/31/10	Ihr 2.3.1.2 c.6												
Adult Fish Counting Visual 0400 - 2000 PST	4/1/10	10/31/10	Ihr 1.2.2												
Operate juvenile facilities	4/1/10	12/15/10	Ihr 2.3.1												
Operate for Juvenile Fish passage	4/1/10	10/31/10	Ihr 2.3.1												
Operate for Adult Fallback	11/1/10	12/15/10	Ihr 2.3.1												
Juvenile Passage Period	4/1/10	12/15/10	Ihr 2.3.1.2												
Doble Tests	8/23/10	8/27/10	App A Ihr 1.2												
1/2 STS May Be Pulled after this date	10/1/10	10/1/10	Ihr 2.3.1.2.b.6												
Draft Final Report	2/10/11	2/10/11	Ihr 2.3.3.3												
Final Report	3/15/11	3/15/11	Ihr 2.3.3.3												

10/1

1.2.2 Adult Migration Timing. Upstream migrants are present at Ice Harbor Dam throughout the year and adult passage facilities are operated year round. Maintenance of adult fish facilities is scheduled for January and February to minimize impacts on upstream migrants. Facilities are usually shut down one shore at a time for maintenance. Adult fish (salmon, steelhead, shad, and lamprey) are counted as per **Table IHR-2**; these data appear daily on the Corps adult count website. Salmon migration timing data appear in **Table IHR-3**. Sturgeon and bull trout are also counted and recorded on the WDFW fish counters' daily summary sheet comments section; and these data are summarized in the Annual Fish Passage Report, but do not appear on the Corps daily website total due to relative infrequency of passage.

Table IHR-2. Adult Fish Counting Schedule at Ice Harbor Dam.

Period	Counting Method
April 1 – October 31	Visual count 0400 - 2000 PST

Table IHR-3. Adult Migration Timing at Ice Harbor Dam from 1962-2009 Based on Fish Counts.

Species	Counting Period	Date of Peak Passage	
		Earliest	Latest
Spring Chinook	4/1 - 6/11	4/22	5/26
Summer Chinook	6/12 - 8/11	6/12	7/23
Fall Chinook	8/12- 10/31	9/2	9/30
Steelhead	4/1 – 10/31	9/15	10/12
Sockeye	4/1 – 10/31	7/1	9/22
Lamprey	4/1 – 10/31	7/21	7/27

2. Project Operation.

2.1. Spill Management. See 2010 Fish Operations Plan (**Appendix E**) for more information.

2.1.1. Involuntary spill at Ice Harbor is the result of river flow exceeding powerhouse capacity, insufficient generation loads to pass the river flow, turbine unit outages (forced or scheduled), or the failure of a key component of the juvenile fish passage facility which forces the project to spill to provide juvenile fish passage. Spill at Ice Harbor will be distributed in accordance with the spill patterns listed in **Tables IHR-11, IHR-12, and IHR-13**. Special spills for juvenile fish passage will be provided as detailed in **Appendices A and E**.

2.2. Dissolved Gas Management and Control. Total dissolved gas (TDG) levels at Ice Harbor Dam are monitored in accordance with the Dissolved Gas Monitoring Program, **Appendix D**.

2.3. Operating Criteria.

2.3.1. Juvenile Fish Passage Facilities. Operate from April 1 through October 31 for juvenile fish passage and from November 1 through December 15 for protecting adult fallbacks. The facilities should be operated according to the following criteria:

2.3.1.1. Winter Maintenance Period (December 16 through March 31). Check and perform maintenance as required on the items listed below.

a. Forebay Area and Intakes.

1. Remove debris from forebay and gatewell slots.
2. Rake trashracks just prior to the operating season.
3. Measure drawdown in gatewell slots after cleaning trashracks and with STSs in place.
4. Inspect and repair gatewell dip net as needed.

b. Submersible Traveling Screens and Vertical Barrier Screens.

1. Maintenance completed on all screens.
2. Inspect STSs prior to installation and operate one trial run (dogged off on deck) to ensure proper operation.
3. Log trial Run.
4. Inspect all VBSs at least once per year with an underwater video camera. Repair as needed.

c. Collection Channel.

1. Water-up valve capable of operating when needed.
2. Orifice lights are operational.
3. Orifices clean and valves operating correctly.
4. Orifice air backflush system works correctly.
5. Netting along handrails maintained and in good condition.
6. Netting or covers over orifice chutes maintained and in good condition.

d. Dewatering Structure and Flume.

1. Inclined screen should be clean and in good condition with no gaps between screen panels, damaged panels, or missing silicone.

2. Screen cleaning system (brush and air flush) maintained and operating correctly.
3. Overflow weirs should be maintained, tested, and operating correctly.
4. All valves should be operating correctly.
5. Flume interior should be smooth with no rough edges.
6. Maintain full-flow PIT tag system as required. Coordinate with PSMFC.

e. Sampling Facilities.

1. Flume dewatering structure should be maintained and in good operating condition with no holes or gaps between dewatering screen panels. Silicone sealer should be in good condition.
2. Flume drop gate should be maintained and in good operating condition.
3. The wet separator and fish distribution system should be maintained and ready for operation as designed.
4. All dewatering screens and seals in separator and flume must be in good condition with no holes or gaps between panels, or sharp edges.
5. All valves and switch gates maintained and in good operating condition.
6. All sampling equipment maintained and in good operating condition.
7. Maintain juvenile PIT tag system as required. Coordinate with PSMFC.

f. Avian Predation Areas (Forebay and Tailrace). Inspect bird wires, water cannon, and other deterrent devices and repair or replace as needed. Where possible, install additional bird wires or other deterrent devices to cover areas of known avian predation activity. Prepare avian abatement contract as needed.

g. Maintenance Records. Record all maintenance and inspections.

2.3.1.2. Fish Passage Period (April 1 through December 15).

a. Forebay Area and Intakes.

1. Remove debris from forebay.
2. Remove debris from trashracks as required to maintain less than 1' of additional drawdown in gate slots. Additional raking may be required when

heavy debris loads are present in the river. Coordinate turbine unit outages with other project work activities, if possible, to minimize turbine unit outages during the spring.

3. Inspect gatewell slots daily for debris, fish buildup, and contaminating substances (particularly oil). Clean gatewells before they become half covered with debris. If, due to the volume of the debris, it is not possible to keep the gatewell surfaces at least half clear, they should be cleaned at least once daily. If flows through an orifice indicate that an orifice may be partially obstructed with debris, the orifice will be closed and backflushed to remove the obstruction. If the obstruction can not be removed, the orifice shall be closed and the alternate orifice for that gatewell slot shall be operated. If both orifices become obstructed or plugged with debris, the turbine unit shall not be operated until the gatewell and orifices are cleared of debris.

4. If a visible accumulation of contaminating substances (such as oil) is detected in a gatewell and it cannot be removed within 24 hours, the gatewell orifices shall be closed immediately and the turbine unit shut down within one hour until the material has been removed and any problems corrected. A preferred method for removing oil from the water surface is to install absorbent (not adsorbent) socks, booms, or pads capable of encapsulating the material, tied off with a rope for later disposal. Action should be taken as soon as possible to remove the oil from the gatewell so the orifice can be reopened to allow the fish to exit the gatewell. Orifices shall not be closed for longer than 48 hours.

5. Dip bulkhead gatewell slots to remove fish prior to installing bulkhead for dewatering bulkhead slot.

b. Submersible Traveling Screens and Vertical Barrier Screens.

1. Operate STSs in cycling mode when average fork length of sub-yearling chinook or sockeye is greater than 120 mm at Lower Monumental collection facility.

2. Operate STSs in continuous operational mode when average fork length of sub-yearling chinook or sockeye is less than 120 mm at Lower Monumental collection facility, or if there is evidence that smaller juvenile fish are present at the project. Return to cycling mode after one week has passed and re-evaluate.

3. Inspect each STS once per month by means of underwater video. Spot check VBSs at the same time.

4. Record STS amp readings daily.

5. If an STS or VBS is damaged or fails during the juvenile fish passage season, follow procedures detailed under unscheduled maintenance of STSs. In no case

should a turbine unit be operated with a missing or a known non-operating or damaged STS or VBS.

6. Up to one-half of the STSs may be removed after October 1 for annual maintenance provided there is no operation of units without screens.
7. Make formal determination at end of season as to adequacy of STS screen mesh and replacement if necessary.
8. Inspect at least 2 VBSs in 2 different turbine units between the spring and summer migration periods. Both turbine units should have been operated frequently during the spring. If a debris accumulation is noted, inspect other VBSs and clean debris as necessary.
9. When extreme cold weather is forecasted (as defined as: anticipated temperatures below 20° Fahrenheit for 24 hours) to occur for an extended period of time between Thanksgiving and December 15, ESBSs and STSs may be removed. The project will first request special permission from CENWW-OD-T. CENWW-OD-T will inform NOAA Fisheries and other FPOM participants of the action.

c. Collection Channel.

1. Orifices clean and operating. Operate at least one orifice per gatewell slot (preferably the north orifice). If the project is operating at MOP, additional orifices may be operated to maintain a full collection channel. If orifices must be closed to repair any part of the facility, monitor the gatewells hourly (unit is operating) or at least every two hours (unit is not operating) for fish condition and behavior. Also see section 3.1.2.2. to determine if the turbine unit must be shut down and if fish must be dipped from the gatewell(s).
2. Orifice lights operational and operating on open orifices. Orifice lights and area lights may be turned off the evening before the channel is dewatered at the end of the season (dewatering occurs on December 16 or later) to encourage fish to exit the channel volitionally. Area lights can be turned on briefly for personnel access if necessary.
3. Replace all burned out orifice lights within 24 hours of notification. Orifice lights shall remain lighted 24 hours/day.
4. Orifice jets hitting no closer than 3' from back wall, collection channel full.
5. Orifice valves are either fully open or closed.
6. Backflush orifices at least once per day. During periods of high fish and debris passage, April 1 through July 31, orifices should be inspected and backflushed

once per 8-hour shift or more frequently as determined by the project biologist, to keep orifices clean.

7. Water-up valve capable of operating when needed.

8. The netting along handrails should be maintained in good condition with no holes or gaps in the netting.

9. Netting or covers over orifice chutes in good condition.

d. Dewatering Structure.

1. Trash sweep operating correctly. The frequency of sweep should be set as necessary to maintain a clean screen, with a minimum operation of at least once per hour. If automated cleaning system problems occur, operate manually at least once per work shift, or more as necessary, to maintain a clean screen.

2. Clean trapezoidal section at least once per day, and more frequently if required, to maintain a clean condition.

3. Check overflow weirs to make sure they are operating correctly, perform maintenance as required.

4. There should be no gaps between screen panels in the inclined screen or holes in the screen panels.

5. Lights at the dewatering structure should be turned off at night, unless needed for personnel access, to encourage fish to move downstream volitionally.

e. Sampling Facilities.

1. All screens should be inspected to make sure there are no holes or sharp edges.

2. Operate wet separator and fish distribution system as designed. Sample fish twice per week during the main juvenile bypass season to monitor juvenile fish descaling and other fish condition parameters. Sampling is not recommended when water temperatures exceed 70° F unless authorized by an ESA permit. Provide information in weekly report.

3. Crowder screen brushes should be maintained in good operating condition with no holes or sharp edges in the crowder screen.

4. Operate pre-anesthetic system as designed.

5. Inform PSMFC, in advance if possible, of situations that cause the PIT tag system to become inoperable (e.g. power outages) or that could result in confounding the interpretation of PIT tag data (e.g. operating in primary bypass

mode without an operational full-flow detector, emergency dewaterings).

f. Avian Predation Areas (Forebay and Tailrace).

1. Bird wires and other avian deterrent devices shall be monitored to assure they are in good condition. Any broken wires or devices shall be replaced as soon as possible.
2. Harassment program in place to deter avian predation in areas actively used by birds and not covered by bird wires or other devices.
3. Project biologists shall routinely monitor project areas to determine areas of active avian predation and, if possible, adjust harassment program to cover these areas or install bird wires or other deterrent devices to discourage avian predation activities.

g. Removable Spillway Weir (RSW). RSW will be in the raised position and operational on the first day of spill.

h. Inspection and Record Keeping. Inspect all facilities according to fish facilities monitoring plans. Record all maintenance and inspections.

2.3.2. Adult Fish Passage Facilities. Operate the adult fish passage facilities according to the following criteria.

2.3.2.1. Winter Maintenance Period (January 1 through February 28).

- a. Inspect all staff gages and water level indicators. Repair and/or clean where necessary.
- b. Dewater all ladders and inspect all dewatered sections of fish facilities for projections, debris, or plugged orifices which could injure fish or impede fish passage up the ladder. Fish ladder exit trashracks must have smooth surfaces where fish pass, and must have downstream edges that are adequately rounded or padded. Spare trashracks should be on hand for use as necessary. Inspect all diffuser gratings and chambers annually by dewatering or by using divers or video inspection techniques. All diffuser gratings and chambers are to be dewatered and physically inspected at least every 3 years. Repair deficiencies.
- c. Inspect for and clean debris from the fish ladder exits. All trashracks and picketed leads must be clean and installed correctly.
- d. Calibrate all water level measuring devices, as necessary, for proper facility operations.
- e. Inspect all spill gates and ensure that they are operable.

- f. Fish pumps maintained and ready for operation.
- g. Maintain adult PIT tag system as required. Coordinate with PSMFC.
- h. Maintain the adult fish trap as required. This can also be done outside of the January-February period because the trap is removable.

2.3.2.2. Fish Passage Period (March 1 through December 31). Note: During extremely high flow periods when tailwater level exceeds elevation 353' msl, the fish pumps will be turned off so that the head differential on the auxiliary water supply conduit ceiling slab does not force water into the warehouse inside the dam.

- a. **Fishway Ladders.** Water depth over weirs: 1' to 1.3'.
- b. **Counting Windows.** The minimum counting slot width should be 18". All equipment should be maintained and in good condition. The counting window and backboard should be cleaned as needed to maintain good visibility.
- c. **Head on all Fishway Entrances.** Head range: 1' to 2'.
- d. **North Shore Entrance (NEW 1).** Elevation of top of gate when on sill = 332.25'.
 - 1. Operate downstream gate closest to shore.
 - 2. Weir depth: 8' or greater below tailwater. At tailwaters less than elevation 340.25', weirs should be on sill. Note that at low river flow and tailwater, some of the diffusers are above tailwater and project may only be able to maintain a 6' weir depth.
 - 3. North Shore Lower Diffuser Gates: If the tailwater is below elevation 344', the diffuser gates should be fully open. If the tailwater is above elevation 344', the diffuser gates should be one-half open.
- e. **North Powerhouse Entrances (NFE 1 and 2).** Elevation at top of gate when on sill = 332.25'.
 - 1. Operate 1 downstream gate.
 - 2. Weir depth: 8' or greater below tailwater. At tailwaters less than elevation 340.25', weirs should be on sill. [**Note:** At low tailwater, weirs will bottom out and will be less than 8' below tailwater.]
- f. **Floating Orifice Gates.** Operate 4 floating orifices, OG1, 4, 10, and 12.
- g. **South Shore Entrance (SFE-1).** Elevation of top of gate when on sill = 332.25'.

1. Operate entrance closest to powerhouse.
2. Weir depth: 8' or greater below tailwater. At tailwaters less than elevation 340.25', weirs should be on sill. [**Note:** At low tailwater, weirs will bottom out and will be less than 8' below tailwater.]

h. Channel Velocity. 1.5' to 4' per second. Ice Harbor Dam monitors water velocity at the junction pool in the lower south fish ladder. The current device utilizes Doppler Technology. Decision for placement was not only what was considered to be the single most representative position, but also the placement for maintenance and ease of installation. In addition, head is measured at the north, north powerhouse, and south fishway entrances.

i. Head on Trashracks.

1. Maximum head of 0.5' on ladder exits.
2. Maximum head on picketed leads shall be 0.3'.
3. Trashracks and picketed leads installed correctly.

j. Staff Gages and Water Level Indicators. All staff gages should be readable at all water levels encountered during the fish passage period. Repair or clean as necessary.

k. Inform PSMFC, in advance if possible, of situations that cause the PIT tag system to become inoperable (e.g. power outages) or that could result in confounding the interpretation of PIT tag data (e.g. emergency dewaterings).

l. Facility Inspections.

1. Powerhouse operators shall inspect facilities once per day shift and check computer monitor information at least once during each back shift.
2. Project biologists shall inspect facilities three times per week. Inspect all facilities according to fish facilities monitoring program.
3. Picketed leads shall be inspected during all inspections to ensure they are clean and in the correct position (all the way down).
4. Project personnel shall check calibration of fishway control system twice per month to ensure that it is kept within calibration. This may be done as part of routine fishway inspections.
5. Inspect fishways daily for foreign substances (particularly oil). If substances are found, corrective actions should be undertaken immediately.

6. Record all inspections.

2.3.3. Facility Monitoring and Reporting. Project biologists shall inspect fish passage facilities at the frequencies listed in the juvenile and adult fish facilities operating criteria sections.

2.3.3.1. Project biologists shall prepare weekly reports, from March 1 through December 31, summarizing project operations. The weekly reports should provide an overview of how the project and the fish passage facilities operated during the week and an evaluation of resulting fish passage conditions.

2.3.3.2. The reports shall include:

- a.** Any out-of-criteria situations observed and subsequent corrective actions taken;
- b.** Any equipment malfunctions, breakdowns, or damage along with a summary of resulting repair activities;
- c.** Adult fishway control calibrations;
- d.** ESBS and VBS inspections;
- g.** Any unusual activities which occurred at the project which may affect fish passage.

2.3.3.3. The weekly reports shall cover a Friday through Thursday time period and shall be sent to CENWW-OD-T by noon the following Monday via electronic mail.

2.3.3.4. Project biologists shall prepare a draft annual report by February 10 and a final report by March 15 summarizing the operation of the project fish passage facilities for the previous year. The annual report shall also include a description of all actions taken to discourage avian predation at the project, with an overview of the effectiveness of the activities in discouraging avian predation.

2.3.3.5. Project biologists also inspect project facilities once per month and during dewaterings for the presence of zebra and quagga mussels. Biologists shall provide a report to CENWW-OD-T on a monthly basis summarizing mussel inspections.

3. Project Maintenance. Project biologists should be present to provide technical guidance at all project activities that may involve fish handling. All dewaterings shall be accomplished in accordance with approved project dewatering and fish handling plans. When river temperatures reach 70 degrees Fahrenheit or greater, all adult fish handling will be coordinated through CENWW-OD-T. Dewatering and fish handling plans were reviewed and revised in 2000 to ensure that they comply with Appendix F, Guidelines for Dewatering and Fish Handling Plans.

3.1. Juvenile Fish Passage Facilities.

3.1.1. Scheduled Maintenance. Scheduled maintenance of the juvenile facilities is conducted during the entire year. Long-term maintenance or modifications of facilities that require them to be out of service for extended periods of time are conducted during the winter maintenance period from December 16 through March 31. During the fish passage season parts of the facilities are maintained on a daily, weekly, or longer interval to keep them in proper operating condition.

3.1.2. Unscheduled Maintenance. Unscheduled maintenance is the correction of any situation that prevents the facilities from operating according to criteria or that will impact fish passage or survival. Maintenance of facilities such as STSs, which sometimes break down during the fish passage season, will be carried out as described below. In these cases, repairs will be made as prescribed and CENWW-OD-T notified for further coordination. Unscheduled maintenance that will have a significant impact on juvenile fish passage shall be coordinated with NOAA Fisheries and other FPOM participants on a case-by-case basis by CENWW-OD-T. CENWW-OD-T will be notified as soon as possible after it becomes apparent that maintenance repairs are required. The Operations Manager has the authority to initiate work prior to notifying CENWW-OD-T when in his opinion delay of the work will result in an unsafe situation for people, property, or fish. Information required by CENWW-OD-T includes:

- a. Description of the problem.
- b. Type of outage required.
- c. Impact on facility operation.
- d. Length of time for repairs.
- e. Expected impacts on fish passage and proposed measures to mitigate them.

3.1.2.1 Submersible Traveling Screens. The STSs are inspected periodically throughout the juvenile migration season with a video monitoring system. If a screen is found to be damaged it will be removed and either replaced with the spare STS or repaired and returned to service. A turbine unit shall not be operated with a known damaged or nonfunctioning STS or without a full complement of STSs. If an STS fails on a weekend or at night when maintenance crews are not available, the respective turbine unit will be shut down and generation switched to another fully screened unit. If all screened turbine units are in service, additional water may be spilled until the effected STS can be removed and repaired or replaced.

3.1.2.2. Gatewell Orifices. Each gatewell has two 12" orifices with air operated valves to allow fish to exit the gatewell. Under normal operation, one orifice per gatewell is operated. To minimize blockage from debris, orifices are cycled and back flushed at least once per day, and more frequently if required by heavy debris loads. If an air valve fails or is blocked with debris, the valve should be closed and the alternate orifice for that gatewell operated until repairs can be made. If both orifices are blocked with debris, damaged, or must be kept closed, the turbine unit will be taken out of service until repairs can be made. If repairs are to take longer than 48 hours,

juvenile fish will be dipped from the gatewell with a gatewell dip basket in accordance with the project dewatering and fish-handling plan.

3.1.2.3. Dewatering Structure. The dewatering structure acts as a transition from the collection channel to the corrugated metal flume. An inclined screen allows excess water to be bled off, with all fish and remaining water transitioning into the corrugated metal flume. The excess water is discharged into the adult fish facility auxiliary water supply system and is also used as the water supply for the sampling facilities. The dewatering structure contains a trash sweep for cleaning the rectangular portion of the inclined screen, and an air blow back system for cleaning the transition (trapezoidal) section of the screen. The dewatering screen has a set of differential pressure sensors for determining head differential across the screen. If the sensors detect a 0.15 foot differential it initiates continuous screen cleaning. If the sensors detect a differential of .30 foot it closes all but 3 orifices (unit 1 orifices remain open) in the juvenile collection channel. Both conditions trigger an alarm at the control panel and in the control room. If the trash sweep breaks and interferes with juvenile fish passage through the structure or if the inclined screen or other component of the structure is damaged, the orifices may need be closed and the collection channel dewatered to allow repairs to be made. If the orifices are closed and the collection channel dewatered, the traveling screens will remain in operation. Fish will be allowed to accumulate in the gatewells for up to 2 days. If repairs are expected to take longer than 2 days, a salvage program will be initiated to remove fish from gatewells, with a gatewell dip basket, until repairs can be made and the system watered up again. While the collection channel is out of service, project personnel shall monitor gatewells for signs of fish problems or mortality. Spill may be provided as an alternative avenue for fish passage during the collection channel outage.

3.1.2.4. Bypass Flume/Pipe. The bypass flume/pipe transports fish to the sampling facilities and to the tailrace below the project. If there is a problem with the flume/pipe that requires it to be dewatered, procedures will be taken similar to **section 3.1.2.3.**

3.1.2.5. Sampling Facilities. Under normal operation, juvenile fish are routed around the sampling facilities, except when sampling is being conducted. If there is a problem with the sampling facilities when it is in operation, the drop gate will be lowered to keep all juvenile fish in the bypass flume/pipe to bypass them directly to the river below the project. All fish in the sampling facility will then be released back to the river prior to sampling if there are any problems with holding them in the sample tank until they can be sampled.

3.2. Adult Fish Passage Facilities.

3.2.1. Scheduled Maintenance. Scheduled maintenance of a facility that must be dewatered to work on or whose maintenance will have a significant effect on fish passage will be done during the January and February winter maintenance period. Maintenance of facilities that will have no effect on fish passage may be conducted at any time. Maintenance is normally conducted on one fish ladder at a time during the winter to provide some fish passage at the project at all times. When facilities are not being maintained during the winter maintenance period, they will be operated according to normal criteria unless otherwise coordinated with NOAA Fisheries and other FPOM participants.

3.2.2. Unscheduled Maintenance. Unscheduled maintenance that will significantly affect the operation of a facility will be coordinated with NOAA Fisheries and other FPOM participants. Coordination procedures for unscheduled maintenance of adult facilities are the same as for juvenile facilities (see section 3.1.2.). If part of a facility malfunctions or is damaged during the fish passage season, and the facility can still be operated within criteria without any detrimental effects on fish passage, repairs may not be conducted until the winter maintenance period or until fewer numbers of fish are passing the project. If part of a facility is damaged or malfunctions that may significantly impact fish passage, it will be repaired as soon as possible.

3.2.2.1 Fish Ladders and Counting Stations. The fish ladders contain fixed weirs, counting stations with picket leads, and fish exits with trashracks. If any part of the ladder fails or is blocked with debris during the fish passage season, efforts will first be made to correct the problem without dewatering the ladder. Trashracks, picket leads, and counting stations can sometimes be repaired or maintained without dewatering the ladder. The decision to dewater the ladder and make repairs during the fish passage season or wait until the winter maintenance period will be made after coordination with the fish agencies and tribes.

3.2.2.2 North Shore Auxiliary Water Supply System. The north shore facilities contain three electric pumps that provide auxiliary water to the diffusers at the bottom of the ladder and at the entrances. During normal operation two pumps are required to provide the necessary auxiliary water. If a pump fails during two-pump operation, the pump on standby will be operated to provide the necessary flows. If two or all three pumps fail, the NEW1 weir will be maintained at a level of 6' below tailwater until repairs are made.

3.2.2.3 South Shore Auxiliary Water Supply System. The south shore auxiliary water is supplied by eight electric pumps and 150 to 180 cfs of excess water from the juvenile fish passage facilities. Fluctuating tailwater levels require from six to eight pumps to be operated to provide the auxiliary water. If one pump fails, a standby pump will be started to keep the fishway within criteria. If more pumps fail, this procedure will continue until all the standby pumps are in operation. If criteria cannot be met due to fish pump outages within 24 hours, the floating orifices should be closed in the following order: OG-12 and OG-10. If the required head differential of 1' to 2' cannot be reached when the floating orifices are closed, SSE 1 and NFE 2 will be closed equally at 1' intervals until it is reached or until the weirs are 5' below tailwater. Then the remaining floating orifices should be closed in the following order: OG-4 and OG-1. If there is still not enough auxiliary water to maintain the head differential on the two main entrances, NFE 2 will be closed, the transportation channel bulkheaded off at the junction pool, and SSE 1 operated as deep as possible to maintain the head differential. If it cannot be maintained at a depth of 6' or greater, the weir will remain at 6' regardless of the head.

3.2.2.4 Fishway Entrances. The fishway entrances consist of main entrance weirs with hoists and automatic controls, and floating orifices which regulate themselves with tailwater fluctuations. If any of the automatic controls malfunction, the weirs can be operated manually by project personnel and kept within criteria. If there is a further failure which prevents the entrance from being operated manually, an alternate entrance will be opened until repairs can be made. If a floating orifice fails, it will be pulled out of the water and the entrance bulkheaded off until the floating orifice is repaired.

3.2.2.5 Diffuser Gratings. Diffuser chambers for adding auxiliary water to fish ladders and collection channels are covered by gratings attached by several different methods. Diffuser gratings are normally checked during the winter maintenance period to make sure they are in place. These inspections are done by either dewatering and physically inspecting the diffuser gratings, or by using underwater video cameras, divers, or other methods. Diffuser gratings may come loose during the fish passage season due to a variety of reasons. Daily inspections of fish ladders and collection systems should include looking for any flow changes that may indicate problems with diffuser gratings. If a diffuser grating is known or suspected to have moved, creating an opening into a diffuser chamber, efforts must immediately be taken to correct the situation and minimize impacts on adult fish in the fishway. Coordination of the problems should begin immediately through the established unscheduled maintenance coordination procedure (see section 3.1.2). If possible, a video inspection should be made as soon as possible to determine the extent of the problem. If diffuser gratings are found to be missing or displaced, creating openings into the diffuser chambers, a method of repair shall be developed and coordinated with the fish agencies and tribes through the established coordination procedure. Repairs shall be made as quickly as possible unless coordinated differently.

4. Turbine Unit Operation and Maintenance.

4.1. Turbine Unit Operation. When in operation, Units will be operated to enhance adult and juvenile fish passage from March 1 through November 30. During this time period Units will be operated as needed to meet generation requirements in the priority order shown in Table IHR-4. Model studies of Ice Harbor Dam show that spilling at lower river flows can cause eddying in front of the powerhouse. To provide the best fish passage conditions during periods of spill, it is important that the Units operate in a specific operating order to minimize eddying conditions. The original and desired unit prioritization is 1, 3, 6, 4, 2, 5. Unit 6 transformer has an internal fault and is generating gases that are indications of arcing and the levels are increasing with time, so it is desired to run this unit in a last on, first off.

With the new Sacajawea 500/115kV transformer in service which is connected to the Ice Harbor-Franklin No. 2 115kV line, IHR should not be run as a single or two unit project if that unit(s) is unit 3 and / or 4 without switching those units to the Ice Harbor-Franklin No. 3 115kV line, disconnecting the Ice Harbor-Franklin No. 2 115kV line from Ice Harbor and disabling the transfer trip for the Ice Harbor-Franklin No. 2 115kV line at Ice Harbor. This switching is necessary to prevent the loss of all Ice Harbor generation and the Sacajawea transformer if there is an outage of the Ice Harbor-Franklin No. 2 115kV line.

If single unit operation is necessary and switching has not occurred in the yard run unit 1, 2, 5, 6. Running units 3 and 4 alone on the Ice Harbor-Franklin No. 2 115kV line can only occur if the powerhouse operator can accomplish the needed switching. .

Table IHR-4. Unit Operating Priority for Ice Harbor Dam.

Season	Time of Day	Unit Priority*
All year-single unit operation w/o switching Switching must occur to return to normal operating priority outlined below	24 hours/day	1,2,5,6
March 1-November 30	24 hours/day	1,3,4,2,5 and 6
December 1 – February 28	24 hours	Any Order for multiple unit operation

4.1.1. The hours of operations may be coordinated and adjusted in-season by CENWW-OD-T (through coordination with TMT) if fish passage or other conditions at the project require it. Unit operating priority may be coordinated differently to allow for fish research, construction, or project maintenance activities. If a turbine unit is taken out of service for maintenance or repair, the next unit in the priority list shall be operated.

4.1.2. Turbine units will be operated within 1% of best efficiency from April 1 through October 31 (as specified in BPA's load shaping guidelines, **Appendix C**) unless operation outside of that range is necessary to:

- 1) meet the load requirements of the BPA Administrator whose load requests will be made in accordance with BPA's policy, statutory requirements, and load shaping guidelines (Appendix C);
- 2) If the turbine unit draft tube is to be dewatered, operate unit with full load for a minimum of 15 minutes prior to installing tail logs. If not possible to load, run unit at speed-no-load for minimum of 15 minutes. This is to reduce the number of fish in the scrollcase prior to installing stop logs;
- 3) operating a turbine unit solely to provide station service; or
- 4) be in compliance with other coordinated fish measures. Project personnel shall record when turbine units are operated outside the 1% efficiency range and shall provide the information to BPA on a weekly basis according to the load shaping guidelines. Between November 1 and March 31, turbine units will continue to be operated within the 1% efficiency range except when BPA load requests require the units to be operated outside the 1% range. Guidelines for operation of the turbine units within the 1% efficiency range at various heads are shown in **Tables IHR-5 through IHR-10**.

4.1.3. All of the lower Snake River powerhouses may be required to keep one generating turbine unit on line at all times to maintain power system reliability. During low flows, there may not be enough river flow to meet this generation requirement and required minimum spill. Under these circumstances the power generation requirement will take precedence over the minimum spill requirement. At Ice Harbor Dam, minimum generation requirements are 8.5 -10.3 kcfs through

turbine units 1 – 3 and 8.5 – 10.3 kcfs for turbine units 4 – 6. Actual attainable minimum generation levels may vary depending on project conditions.

4.2. Turbine Unit Outages During High River Flow Periods. During high spring flows, turbine unit outages for NERC regulatory requirements, inspecting fish screens, repairing research equipment such as hydroacoustic or radio telemetry equipment, and other fish items may cause increased spill at a project in order to maintain reservoir levels within operating levels. This may result in TDG levels exceeding standards. It is important that this work be conducted when scheduled to ensure that facilities are working correctly and not injuring migrating fish, and that important fish research data is collected. To facilitate this work, reservoir storage may be utilized to minimize impacts from taking turbine units out of service and increasing spill. At Ice Harbor, this special operation may take place when river flows are above 100 kcfs or when increasing spill levels will result in TDG levels exceeding standards. The activities covered under these operations will be coordinated with and approved by the TMT whenever possible.

4.2.1. For scheduled inspection or repair of research equipment, reservoirs shall be drafted to MOP and allowed to fill to 1' above the 1' MOP operating range as the work is accomplished. After the work, reservoirs will be slowly drafted back to the MOP operating range. When inspection or repair work can be scheduled ahead of time, the following process will be followed:

- a. Project personnel shall schedule turbine unit outages through the approved turbine outage scheduling procedure by noon of the Tuesday of the week prior to the outage.
- b. Project personnel shall also contact CENWW-OD-T and RCC by the same time period and inform them of the intended work.
- c. The RCC will coordinate the work activities through the TMT.
- d. After coordination with the TMT, RCC shall issue a teletype through the CBTT issuing instructions to project and BPA personnel for the scheduled work.
- e. Spill will be increased by one spill bay stop setting (about 1.7 kcfs) above passing inflow to slowly lower the level of Ice Harbor pool to MOP prior to the scheduled work taking place.
- f. When the work takes place, additional spill will not be provided and the reservoir will be allowed to refill until the reservoir is 1' above the normal MOP range (a 2' pondage from where the pool was when the work started). At this point, screen inspections shall stop. (At Snake River projects, this should allow about one normal workday for the scheduled work.)
- g. At the conclusion of the work, the reservoir shall be drafted back down to the MOP range utilizing a one spill bay stop increase in spill above passing inflow.

h. If work, such as screen inspections, is not finished, project personnel shall schedule another turbine unit outage for a date where it can be implemented again.

4.2.2. If the work that needs to be done is of an emergency nature that does not normally require the turbine unit to be taken out of service (such as a failed hydroacoustic transducer versus a failed fish screen), and can not wait for the above process to be implemented, project personnel shall notify CENWW-OD-T and RCC to get approval to do the work. If approval to do the work is given, the turbine unit shall be taken out of service and the reservoir level allowed to increase until it reaches 1' above the MOP operating range. At this point, the turbine unit must be returned to service and the reservoir will be drafted back to the MOP range using one spill bay stop setting above passing inflows.

4.3. Turbine Unit Maintenance. The project turbine unit maintenance schedule will be reviewed annually by project and Operations Division biologists for fish impacts. If possible, maintenance of priority units will be scheduled for non-fish passage periods, or when there are low numbers of fish passing the project. Each turbine unit requires annual maintenance that may take from several days to two weeks. Annual maintenance of all turbine units is normally scheduled during the mid-July to late November time frame. The maintenance of priority units for adult passage is normally conducted in mid-August, when fewer adults are migrating, to minimize impacts on migrating adults. Turbine units may occasionally require overhauls to repair major problems with the turbine or generator. Overhauls may take over one year to accomplish. Turbine units, governors, exciters, and control systems require periodic maintenance, calibration, and testing which may take them outside of the 1% turbine efficiency range. This work will be scheduled in compliance with BPA load shaping guidelines (**Appendix C**) to minimize impacts on juvenile fish.

4.3.1. Unwatering turbine units should be accomplished in accordance with project dewatering plans. If the turbine unit draft tube is to be dewatered, operate unit with full load for a minimum of 15 minutes prior to installing tail logs. If not possible to load, run unit at speed-no-load for minimum of 15 minutes. This is to reduce the number of fish in the scrollcase prior to installing stop logs. If a turbine unit is out of service for maintenance for an extended period of time without tailrace stoplogs in place, efforts should be made to not open the wicket gates if the scroll case must be dewatered at a later date without the unit being spun before hand.

4.3.2. Units may be operationally tested for up to 30 minutes before going into maintenance status by running the unit at speed no load and various loads within the 1% criteria to allow pre-maintenance measurements and testing AND TO ALLOW ALL FISH TO MOVE THROUGH THE UNIT. Units may be operationally tested after maintenance or repair while remaining in maintenance or forced outage status. Operational testing may consist of running the unit for up to a cumulative time of 30 minutes (within 1% criteria) before it is returned to operational status. Operational testing OF UNIT UNDER MAINTENANCE is in addition to a unit in run status (E.G. MINIMUM GENERATION) required for power plant reliability. Operational testing may deviate from fish priority units and may require water that would otherwise be used for spill if the running unit for reliability is at its 1% minimum load. Water will be used from the powerhouse allocation if possible, and water diverted from spill for operational testing will be minimized to that necessary to maintain and assure generation system reliability.

Table IHR-5. The 1% Best Efficiency Ranges for Turbine Units 1 and 3 with STSs.

Head (Ft)	Lower Generator Limits		Upper Generator Limits	
	(MW)	(CFS)	(MW)	(CFS)
85	51.7	8,417	83.6	13,590
86	52.6	8,443	84.6	13,585
87	53.4	8,469	85.6	13,580
88	54.2	8,494	86.6	13,574
89	55.0	8,518	87.6	13,569
90	55.8	8,542	88.6	13,563
91	56.5	8,548	89.8	13,585
92	57.1	8,554	90.9	13,607
93	57.8	8,559	92.1	13,628
94	58.5	8,565	93.2	13,649
95	59.2	8,570	94.4	13,669
96	59.9	8,589	95.3	13,662
97	60.7	8,607	96.3	13,655
98	61.5	8,624	97.3	13,648
99	62.2	8,641	98.2	13,641
100	63.0	8,658	99.2	13,634
101	64.0	8,707	99.9	13,590
102	65.0	8,354	100.6	13,547
103	66.0	8,804	101.3	13,505
104	67.0	8,850	102.0	13,463
105	68.0	8,896	102.6	13,422

Table IHR-6. The 1% Best Efficiency Ranges for Turbine Units 1 and 3 Without STSs.

Head (FT)	Lower Generator Limits		Upper Generator limits	
	(MW)	(CFS)	(MW)	(CFS)
85	51.9	8340	89.9	14,452
86	52.7	8367	91.0	14,447
87	53.5	8392	92.0	14,441
88	54.3	8417	93.1	14,436
89	55.1	8441	94.2	14,430
90	55.9	8465	95.3	14,424
91	56.6	8471	96.5	14,448
92	57.3	8477	97.8	14,471
93	58.0	8482	99.0	14,494
94	58.6	8,047	100.3	14,516
95	59.3	8,052	101.5	14,537
96	59	8,070	102.5	14,530
97	59	8,087	103.5	14,522
98	60	8,103	104.6	14,515
99	61	8,119	105.7	14,508
100	62	8,135	106.7	14,500
101	62	8,182	107.4	14,454
102	63	8,227	108.2	14,408
103	64	8,272	108.9	14,363
104	65	8,316	109.7	14,319
105	66	8,359	110.4	14,275

NOTE: Table based on the 1978 model test and 2006 Unit 3 index test (IHR -5&6 revised 2008)

Table IHR-7. The 1% Best Efficiency Ranges for Turbine Units 4-6 with STSs.

Head (FT)	Lower Generator Limits		Upper Generator limits	
	(MW)	(CFS)	(MW)	(CFS)
85	58.9	9,369	93.1	14,810
86	59.7	9,380	94.4	14,824
87	60.6	9,390	95.7	14,838
88	61.4	9,400	97.0	14,851
89	62.2	9,410	98.2	14,864
90	63.0	9,419	99.5	14,876
91	63.7	9,416	100.7	14,885
92	64.5	9,414	102.0	14,895
93	65.2	9,411	103.2	14,904
94	65.9	9,409	104.5	14,912
95	66.6	9,406	105.7	14,921
96	67.5	9,416	106.7	14,892
97	68.3	9,425	107.7	14,864
98	69.1	9,434	108.6	14,836
99	69.9	9,442	109.6	14,809
100	70.7	9,451	110.6	14,782
101	71.4	9,446	112.9	14,939
102	72.0	9,441	115.1	15,093
103	72.7	9,436	117.4	15,224
104	73.3	9,431	119.7	15,392
105	74.0	9,426	121.9	15,538

Table IHR-8. The 1% Best Efficiency Ranges for Turbine Units 4-6 without STSs.

Head (FT)	Lower Generator Limits		Upper Generator limits	
	(MW)	(CFS)	(MW)	(CFS)
85	62.0	9,745	110.7	17,413
86	62.8	9,756	112.3	17,430
87	63.7	9,767	113.8	17,447
88	64.5	9,777	115.3	17,462
89	65.4	9,787	116.8	17,477
90	66.3	9,797	118.3	17,492
91	67.0	9,794	119.8	17,503
92	67.8	9,792	121.3	17,515
93	68.6	9,789	122.7	17,525
94	69.3	9,787	124.2	17,535
95	70.1	9,784	125.7	17,545
96	70.9	9,794	126.8	17,512
97	71.8	9,804	128.0	17,479
98	72.7	9,813	129.2	17,446
99	73.5	9,822	130.3	17,414
100	74.4	9,831	131.5	17,382
101	75.1	9,825	134.2	17,567
102	75.7	9,820	136.9	17,748
103	76.4	9,815	139.6	17,926
104	77.1	9,810	142.3	18,100
105	77.8	9,805	145.0	18,271

NOTE: Table based on the 1978 model test and 2006 Unit 6 index test (IHR -7&8 revised 2008)

Table IHR-9. The 1% Best Efficiency Ranges for Turbine Unit 2 with STSs.

Head (Ft)	Lower Generator Limits		Upper Generator Limits	
	(MW)	(CFS)	(MW)	(CFS)
85	67.6	10,986	72.9	11,854
86	68.6	11,017	73.9	11,864
87	69.6	11,047	74.8	11,873
88	70.6	11,077	75.8	11,882
89	71.7	11,105	76.7	11,890
90	72.7	11,133	77.7	11,899
91	73.4	11,120	78.7	11,917
92	74.2	11,107	79.8	11,936
93	75.0	11,093	80.8	11,953
94	75.8	11,080	81.8	11,970
95	76.5	11,068	82.9	11,987
96	77.3	11,071	83.5	11,955
97	78.2	11,073	84.2	11,924
98	79.0	11,076	84.8	11,894
99	79.8	11,079	85.5	11,864
100	80.6	11,082	86.1	11,835
101	81.5	11,096	87.1	11,852
102	82.5	11,110	88.1	11,869
103	83.4	11,124	89.1	11,886
104	84.3	11,138	90.1	11,902
105	85.2	11,151	91.1	11,918

NOTE: Based on the 1956 Model Test and 2008 Unit 2 Index Test (IHR new 2008)

Table IHR-10. The 1% Best Efficiency Ranges for Turbine Unit 2 Without STSs.

Head (FT)	Lower Generator Limits		Upper Generator limits	
	(MW)	(CFS)	(MW)	(CFS)
85	68.7	11,032	74.0	11,896
86	69.7	11,064	75.0	11,905
87	70.7	11,094	76.0	11,914
88	71.8	11,124	76.9	11,923
89	72.8	11,153	77.9	11,932
90	73.8	11,181	78.8	11,940
91	74.6	11,167	79.9	11,959
92	75.4	11,154	80.9	11,978
93	76.2	11,141	82.0	11,995
94	76.9	11,128	83.1	12,013
95	77.7	11,115	84.1	12,029
96	78.6	11,118	84.8	11,998
97	79.4	11,121	85.4	11,966
98	80.2	11,124	86.1	11,936
99	81.1	11,127	86.7	11,906
100	81.9	11,130	87.4	11,877
101	82.8	11,144	88.4	11,894
102	83.8	11,158	89.4	11,911
103	84.7	11,172	90.4	11,928
104	85.6	11,186	91.4	11,944
105	86.5	11,199	92.4	11,960

NOTE: Table based on the 1956 model test and 2008 Unit 2 Abbrev. index test (IHR new 2008)

5. Forebay Debris Removal. Debris at projects can impact fish passage conditions. Debris can plug or block trashracks, VBSs, gatewell orifices, dewatering screens, separators, and facility piping resulting in impingement, injuries, and descaling of fish. Removing debris at its source in the forebay is sometimes necessary to maintain safe and efficient fish passage conditions, navigation, and other project activities. Debris can be removed from the forebay by: physically encircling the debris with log booms and pulling it to shore with boats where it can be removed with a crane, removing the debris from the top of the dam using a crane and scoop, or passing the debris through the spillway with special powerhouse operations and spill. The preferred option is to remove debris at each project when possible to avoid passing debris on to the next project downstream. This is not always possible at each project, as some projects do not have forebay debris removal capability. In this case, the only viable alternative is to spill the debris.

5.1. All special spills (other than normal spill patterns for ongoing spill operations) and project operations for passing debris will be coordinated prior to the operations taking place. Each project shall contact CENWW-OD-T at least two workdays prior to the day they want the special project operations for spilling to pass debris. CENWW-OD-T shall coordinate the special operations with RCC, NOAA Fisheries, and other FPOM participants. Project personnel shall provide CENWW-OD-T the reason for the debris spill request, including an explanation of project facilities being impacted by the debris, the date and time of the requested spill, and any special powerhouse or other operations required to move the debris to the spillway. When a debris spill is coordinated and approved, RCC shall issue a teletype detailing the specifics of the special operations.

Table IHR-11. Ice Harbor High Gate Spill Pattern. Deflectors in all Bays. No RSW.

Spill Bay										Total Stops	Total Spill (kcfs)
1	2	3	4	5	6	7	8	9	10		
		5								5	8.5
		5							1	6	10.2
		5						1	1	7	11.9
		5						1.5	1.5	8	13.6
		5						2	2	9	15.4
		5		5						10	17.0
		5		5					1	11	18.7
		5.5		5.5					1	12	20.4
		5.5		5.5				1	1	13	22.1
		5.5		5.5				1.5	1.5	14	23.8
		5		5		5				15	25.5
		5		5		5			1	16	27.2
		5.5		5.5		5			1	17	28.9
		5.5		5.5		5.5			1.5	18	30.5
		6		6		6			1	19	32.0
		5		5		5		5		20	34.0
		5		5		5		5	1	21	35.7
		5.5		5		5		5.5	1	22	37.3
		5.5		5.5		5.5		5.5	1	23	39.0
		6		5.5		5.5		6	1	24	40.6
		6		6		6		6	1	25	42.1
		5	5	5		5		5	1	26	44.2
		5.5	5	5		5		5.5	1	27	45.8
		5.5	5	5.5		5.5		5.5	1	28	47.5
		5.5	5.5	5.5		5.5		6	1	29	49.1
		5.5	5.5	6		6		6	1	30	50.7
		6	6	6		6		6	1	31	52.2
		6	6	6.5		6.5		6	1	32	54.0
		6.5	6.5	6.5		6.5		6	1	33	55.8
		6	6	5	5	5		6	1	34	57.5
		6	6	5	5	6		6	1	35	59.1
		6	6	6	5	6		6	1	36	60.7
		6	6	6	6	6		6	1	37	62.3
		6	6	6	6	7		6	1	38	64.1
		6	6	6	6	7		7	1	39	65.7
		6	6	6	7	7		7	1	40	67.4
		6	6	7	7	7		7	1	41	69.1
		6	7	7	7	7		7	1	42	70.8
		7	7	7	7	7		7	1	43	72.5
6		6	6	6	6	7		6	1	44	74.1
6		6	6	6	7	7		6	1	45	75.8
6		6	6	7	7	7		6	1	46	77.5
6		6	7	7	7	7		6	1	47	79.2
6		7	7	7	7	7		6	1	48	80.9
6		6	6	6	6	6	6	6	1	49	82.5

Table IHR-11 . Ice Harbor High Gate Spill Pattern. Deflectors in all Bays. No RSW.

Spill Bay										Total Stops	Total Spill (kcfs)
1	2	3	4	5	6	7	8	9	10		
6		6	6	6	6	7	6	6	1	50	84.2
6		6	6	6	7	7	6	6	1	51	85.9
6		6	6	6	7	7	6	7	1	52	87.6
6		6	6	7	7	7	6	7	1	53	89.3
6		6	7	7	7	7	6	7	1	54	91.0
6		7	7	7	7	7	6	7	1	55	92.7

Table IHR-12. Ice Harbor RSW 30% Spill Pattern

Spill Bay										Total Stops	Total Spill (kcfs)
1	2	3	4	5	6	7	8	9	10		
0	RSW	0	0	0	0	0	0	0	0	0	8.4
0	RSW	0	0	0	0	0	0	0	1	1	10.1
0	RSW	0	0	0	0	0	0	1	1	2	11.8
0	RSW	0	0	0	0	0	1	1	1	3	13.5
0	RSW	0	0	0	0	1	1	1	1	4	15.2
0	RSW	0	0	0	1	1	1	1	1	5	17.0
0	RSW	5	0	0	0	0	0	0	1	6	18.6
0	RSW	5	0	0	0	0	0	1	1	7	20.3
0	RSW	5	0	0	0	0	1	1	1	8	22.0
0	RSW	5	0	0	0	1	1	1	1	9	23.7
0	RSW	5	0	0	1	1	1	1	1	10	25.4
0	RSW	5	0	5	0	0	0	0	1	11	27.0
0	RSW	5	0	5	0	0	0	1	1	12	28.7
0	RSW	5	0	5	0	0	1	1	1	13	30.4
0	RSW	5	0	5	0	0	1	1	2	14	32.1
0	RSW	5	0	5	0	0	1	2	2	15	33.8
0	RSW	5	0	5	0	0	2	2	2	16	35.5
0	RSW	6	0	5	0	0	2	2	2	17	37.2
0	RSW	6	0	6	0	0	2	2	2	18	38.8
0	RSW	6	0	6	0	1	2	2	2	19	40.5
0	RSW	6	0	6	0	2	2	2	2	20	42.2
0	RSW	5	0	5	0	5	2	2	2	21	44.0
0	RSW	5	0	5	0	6	2	2	2	22	45.6
0	RSW	5	0	6	0	6	2	2	2	23	47.3
0	RSW	6	0	6	0	6	2	2	2	24	48.9
0	RSW	6	0	6	0	6	2	3	2	25	50.6
0	RSW	6	0	6	0	6	2	4	2	26	52.3
0	RSW	6	0	6	0	6	2	5	2	27	54.0
0	RSW	6	0	6	0	6	2	6	2	28	55.6
0	RSW	6	0	6	1	6	2	6	2	29	57.3
0	RSW	6	0	6	2	6	2	6	2	30	59.0
0	RSW	6	0	6	3	6	2	6	2	31	60.7
0	RSW	6	0	6	4	6	2	6	2	32	62.4
0	RSW	6	0	6	5	6	2	6	2	33	64.1
0	RSW	6	0	6	6	6	2	6	2	34	65.7

Note: The normal minimum spill level is 15.2 kcfs.

Table IHR-13. Ice Harbor RSW 45 kcfs/Spill Cap Spill Pattern.

Spill Bay										Total Stops	Total Spill (kcfs)
1	2	3	4	5	6	7	8	9	10		
0	rsw	0	0	0	0	0	0	0	0	0	8.4
0	rsw	0	0	0	0	0	0	0	1	1	10.1
0	rsw	0	0	0	0	0	0	1	1	2	11.8
0	rsw	0	0	0	0	0	1	1	1	3	13.5
0	rsw	0	0	0	0	1	1	1	1	4	15.2
0	rsw	0	0	0	1	1	1	1	1	5	17.0
0	rsw	0	5	0	0	0	0	0	1	6	18.6
0	rsw	0	5	0	0	0	0	1	1	7	20.3
0	rsw	0	5	0	0	0	1	1	1	8	22.0
0	rsw	0	5	0	0	1	1	1	1	9	23.7
0	rsw	0	5	0	5	0	0	0	0	10	25.3
0	rsw	0	5	0	5	0	0	0	1	11	27.0
0	rsw	0	5	0	5	0	0	1	1	12	28.7
0	rsw	0	5	0	5	0	1	1	1	13	30.4
0	rsw	0	5	0	5	1	1	1	1	14	32.1
0	rsw	0	5	0	5	1	1	1	2	15	33.8
0	rsw	0	5	0	5	1	1	2	2	16	35.5
0	rsw	0	5	0	5	1	2	2	2	17	37.2
0	rsw	0	5	0	5	2	2	2	2	18	38.9
0	rsw	0	5	0	5	2	2	2	3	19	40.6
0	rsw	0	5	0	5	2	2	3	3	20	42.3
0	rsw	0	5	0	5	5	2	2	2	21	44.0
0	rsw	0	6	0	5	5	2	2	2	22	45.6
0	rsw	0	6	0	6	5	2	2	2	23	47.3
0	rsw	0	6	0	6	6	2	2	2	24	48.9
0	rsw	0	6	5	5	5	1	1	2	25	50.7
0	rsw	0	6	5	5	5	1	2	2	26	52.4
0	rsw	0	6	5	5	5	2	2	2	27	54.1
0	rsw	0	6	6	5	5	2	2	2	28	55.7
0	rsw	0	6	6	5	5	2	3	2	29	57.4
0	rsw	0	6	6	5	5	2	4	2	30	59.1
0	rsw	0	6	6	5	5	2	5	2	31	60.7
0	rsw	0	6	6	5	5	3	5	2	32	62.4
0	rsw	0	6	6	5	5	4	5	2	33	64.1
0	rsw	0	6	6	5	5	5	5	2	34	65.8
0	rsw	1	6	6	5	5	5	5	2	35	67.5
0	rsw	2	6	6	5	5	5	5	2	36	69.2
0	rsw	3	6	6	5	5	5	5	2	37	70.9
0	rsw	4	6	6	5	5	5	5	2	38	72.6
0	rsw	5	6	6	5	5	5	5	2	39	74.2
0	rsw	6	6	6	5	5	5	5	2	40	75.9

Note: The normal minimum spill level is 15.2 kcfs.

Table IHR-13. Ice Harbor RSW 45 kcfs/Spill Cap Spill Pattern (continued).

Spill Bay											
1	2	3	4	5	6	7	8	9	10	Total Stops	Total Spill (kcfs)
0	rsW	6	6	6	6	5	5	5	2	41	77.5
0	rsW	6	6	6	6	6	5	5	2	42	79.2
0	rsW	6	6	6	6	6	6	5	2	43	80.9
0	rsW	6	6	6	6	6	6	6	2	44	82.5
0	rsW	7	6	6	6	6	6	6	2	45	84.1
0	rsW	7	7	6	6	6	6	6	2	46	85.7
0	rsW	7	7	7	6	6	6	6	2	47	87.3
0	rsW	7	7	7	7	6	6	6	2	48	88.9
0	rsW	7	7	7	7	7	6	6	2	49	90.5
0	rsW	7	7	7	7	7	7	6	2	50	92.1
0	rsW	7	7	7	7	7	7	7	2	51	93.7
0	rsW	8	7	7	7	7	7	7	2	52	95.3
0	rsW	8	8	7	7	7	7	7	2	53	96.9
0	rsW	8	8	8	7	7	7	7	2	54	98.5
0	rsW	8	8	8	8	7	7	7	2	55	100.1
0	rsW	8	8	8	8	8	7	7	2	56	101.7
0	rsW	8	8	8	8	8	8	7	2	57	103.3
0	rsW	8	8	8	8	8	8	8	2	58	104.9
0	rsW	9	8	8	8	8	8	8	2	59	106.6
0	rsW	9	9	8	8	8	8	8	2	60	108.3
0	rsW	9	9	9	8	8	8	8	2	61	110.0
0	rsW	9	9	9	9	8	8	8	2	62	111.7
0	rsW	9	9	9	9	9	8	8	2	63	113.4